







Basic Operating Instructions for NewLine Interactive Panel

- 1. Before operating the NewLine Interactive Panel make sure the power cord is plugged into both the panel (labeled 2 in the diagram below) and the wall receptacle. Also make sure that the master power switch (labeled 1 in the diagram below) is in the ON position, denoted by a line. If it is in the position denoted by a circle, the panel is switched off.



2. Next, find the appropriate cable for the type of device you will be connecting to the panel. This will either be an HDMI or a VGA cable. Follow the diagrams below to connect these cables to the panel. Note that an audio cable is not needed for the HDMI connection as audio is transferred through this cable simultaneously with video. The VGA cable will be blue and the audio cable will be green. The USB touch cable and HDMI cable can come in a variety of colors, however, usually they will both be black.







VGA Connection



3. The diagram below shows the main operation buttons. To turn the panel on press the power button located in the bottom left corner of the panel. The other buttons near the power button perform various functions. Refer to the diagram for more information on these buttons.

◆ **Front Buttons**



Buttons	Operations	Functions
	Short press	Power on/off <ul style="list-style-type: none"> • Steady red color: Display is in shut down mode • Steady blue color: Display is on and working
Home	Short press	Go to the home page
Return	Short press	Return to the last menu/Exit
Menu	Short press	Open the Settings menu
	Long press for more than 2 seconds	Lock the screen
Vol-	Short press	Decrease the sound volume
	Long press for more than 1 second	Continuously decrease the sound volume
Vol+	Short press	Increase the sound volume
	Long press for more than 1 second	Continuously increase the sound volume

4. After the panel has been plugged in and turned on the diagram below shows how the various sections that are displayed on the “home screen” are used in the operation of the panel.



1 Logo (Shortcut to Settings)

2 Clock (Shortcut to Clock)

3 Date and Week

4 Side Toolbar








5 Status Bar and Settings

6 Main Icon

7 Preview Window for Signal Source

When there is a device plugged into either the HDMI or VGA ports on the panel, the screen on the right of panel will be lit up in white showing where it is plugged in. You can click once on the highlighted area and a preview will be shown in the window to the left of that area. Double clicking on this preview will bring up this device, in our case the teacher laptop/PC.

5. On either side of the panel screen is a small blue colored toolbar. The diagram below shows what each icon means and what action it performs.

Icon	Functions
	Enter annotation mode, and click again to stop annotation and take a screenshot.
	Access discussion mode.
	Go to Home page.
	Return to the previous menu/Exit an app
	Go to the internal PC source.
	Manage currently running applications. Slide up/down the currently running application or click “x” at the upper right corner to close the application.
	Go to your favorite source. You can set favorite source in the “tool bar” submenu in the system settings.

6. For more detailed information about the NewLine Interactive panel you can view the product user manual at http://www.quitmanschools.org/wordpress/wp-content/uploads/docs/technology/TechFAQ/RS_Series_UserManual.pdf