

## Removing a PIN Code On A Promethean Board

1. Press the **^ icon** at the bottom of the Promethean Panel
2. Check to make sure that you are logged in as "Owner"
3. Press **Locker**
4. Press **Settings**
5. Press **Security + Location**
6. Press **Screen Lock**
7. Enter the PIN you created
8. Select **None** from the options listed
9. Press **Yes, remove**